

ELECTRICAL INSTALLATION AND ESTIMATING  
ELECTRICAL ENGINEERING  
6<sup>TH</sup> SEMESTER

PRAKASH KUMAR, 14/EL-64

[I.E=INDIAN ELECTRIC]

## Estimating:-

**DEF<sup>n</sup>** - Estimating is a art of assessment of quantities of different items required for executing a work before actually carrying out the work

## Definitions:-

(1) Ampere → It is the unvarying electric current which, when passed through a solution of nitrate of silver at the rate of 0.00118 of a gram per second

\* It is the Unit of electric current

(2) Volt → It is the electric pressure which, when steadily applied to a Conductor, the resistance of which is one ohm, will produce a current of 1 ampere

\* It is the Unit of emf

(3) Voltage → It is the difference of electrical potential measured in volt bet<sup>n</sup> any two conductor or bet<sup>n</sup> any part of single conductor and earth as measured

by a suitable voltmeter

It is one of four types.

- A. Low voltage
- B. medium voltage
- C. High voltage
- D. Extra high voltage.

#### A. Low voltage

\* It is the voltage which doesn't exceed 250 volt under normal conditions subject however to the percentage of variation allowed by the I-E rules

#### B. Medium voltage.

\* It is the voltage which doesn't exceed 650 volt under normal condit<sup>n</sup> subjected to the percentage of variat<sup>n</sup> allowed by the IE rule

#### C. High voltage.

\* It is the voltage which doesn't exceed 33,000 volt under normal condition subjected to the percentage of variation allowed by the IE rule

#### D. Extra High voltage.

\* It is the voltage which exceeds 33 KV under normal condit<sup>n</sup> subjected to the percentage of variation allowed by the IE rule

(4) Circuit → It is an arrangement of conductors & conductors for the purpose of conveying energy and forming a system or a branch of system

(5) Circuit breaker → It is a device which is capable of making and breaking the circuit under all conditions and unless otherwise specified so designed to break the circuit automatically under any abnormal condition

(6) Apparatus → Apparatus means electrical apparatus and includes all the fittings, accessories and appliances in which conductors are used

(7) Conductor → It is an a wire, cable, bar, tube, rail or plate used for conducting energy and so arranged as to be electrically connected to a system

(8) Live → It means the system is electrically charged

(9) Dead → It means the system is disconnected from any live/charged system i.e. its potential is equal to the earth potential

\* The apparatus separated from a live conductor by a spark gap shall not be deemed to be dead

(10) Cable → It means a length of insulated single core or two or more such conductors each provided with its poor insulation which are laid together

(11) Bare → It means the conductor not covered with any insulating material

(12) Cut-out →

It is an appliance for automatically interrupting the transmission of energy through any conductor when the current rises above a predetermined amount

05-02-2017

(13) Conduit → It means rigid or flexible metallic tubing or mechanically strong and fire resisting non-metallic tubing in which the cables may be drawn for the purpose of affording it

(14) System → It means an electrical system in which all the conductors & apparatus are electrically connected to a common source of electric supply

(15) Danger :- 

It means danger to health or life or any part of body from shock, burn or other injury to life or property or fire explosion, attend'g up-on the general transmission, distribution or use of energy

(16) Installation :- It means any composite electrical unit used for the purpose generating, transmitting, converting, distributing or utilizing energy

(17) Earthing system :- It means an electrical system in which all the conductors are earthed

(18) Earthline space :- It means the horizontal distance b/w two adjacent supporting poles on an overhead conductor

19) switch gear:- It shall denote switches, breakers, cutouts and other protective apparatus used for operating, regulating and control of circuits.

20) Electrician:- It means person over 21 years of age who is competent for the purpose of the rule in which the term is used and who has been appointed ~~intake~~ by the owner, agent or manager of any Company

General Conditions relating to supply and use of Energy.

09/01/2017

Rule 45

\* The max<sup>m</sup> voltage regulat<sup>n</sup>. for low & medium voltage is  $\pm 5\%$  as per I.E. rule

\* As per I.B. rule the max<sup>m</sup> voltage regulat<sup>n</sup> for high & extra high voltage  $\pm 12.5\%$  according to the IE rule.

Rule 55:-

\* As per I.E. rule the max<sup>m</sup> frequency regulat<sup>n</sup> is  $\pm 3\%$

Rule 56:-

17/01/2017

{(P.C)- Rainforced Cement Concrete}  
(P.C)-pre-stressed Cement Concrete }

Short Q.

? what is the max voltage regulation for H.V & E.H.V line as per I.E rule.

Ans The max<sup>m</sup> voltage regulat<sup>n</sup>. for H.V & E.H.V line as per I.E rule is  $\pm 12.5\%$ .

? what is the max<sup>m</sup> voltage regulat<sup>n</sup> for low & medium V line as per I.E. rule.

Ans The max<sup>m</sup> voltage regulat<sup>n</sup> for low & medium Voltage line as per I.E rule is  $\pm 5\%$ .

? Define low voltage, medium voltage, high voltage, extra H.V, Ampere, Electrician as per I.E rule.

L.V → which voltage can't exceed 250 V under normal condit<sup>n</sup> subjected to the percentage of variat<sup>n</sup> allowed by the I.E rule.

M.V → It is a voltage which can't exceed 650 V under normal condit<sup>n</sup> subjected to the variat<sup>n</sup> allowed by the I.E rule.  
percentage of

H.V → it is the voltage which can't exceed 33 KV under normal condit<sup>n</sup> subjected to the percentage of variation allowed by the I.E rule.

E-H.V → It is the voltage which can exceed above 33 KV under normal condit<sup>n</sup> subjected to the percentage of variat<sup>n</sup> allowed by the I.E rule.

Ampere → It is a unvarying electric current, when it passed through the column of nitrate silver at the rate of 0.00118 of a g/sec.

\* Also it the unit of current.

Electrician → Electrician means, whose age limits 21 years old, he is appointed by an owner or manager. That man know about all the Indian electricity rules.

## OVERHEAD INSTALLATION 20/01/2017

### (H.T DISTRIBUTION)

Generally for distributing electrical energy we have two types of system such as

(a) High tension (H.T) distribution

(b) low " (L.T) "

\* It depends on the voltage to be supplied so it may be L.H or H.T distribution but following accessories must be used in overhead distribution system

#### 1. supports

\* usually electric poles or towers are called as supports. The main function is to support the conductors so as to keep the conductors at a suitable level from the ground.

\* Generally for L.T distribution we use 8 m RCC pole (Prestressed cement concrete) or R.C.C poles and also rail poles of 9 m or 10 m height

\* Similarly for H.T distribution we use 9 m pole or RCC pole and joists, rail poles of height 12 m depending on the voltage to be supplied and various regions, we also use the towers in H.T distribution

## Factors covering height of pole

following points are the important factors for which height of the pole is fixed to a certain limit

- \* The minimum clearance of the live conductor from the ground
- \* The no. of conductors to be carried out and minimum vertical clearance bet<sup>n</sup> the conductors & ground
- \* The length of the pole is to be buried in the ground (generally  $\frac{1}{6}$  of the total height must be buried in the ground in normal soil).

## Cross-arm

It is cross piece fitted to the pole top at the end portion by means of brackets is known as pole bracket, such cross arms used to hold the insulators

usually in the distribution line MS channel, angle iron, V-shaped, U-shaped or zig-zag cross arm are used

In order to prevent arcing bet<sup>n</sup> two conductors the cross arm must be design so as to hold the insulators as per the following applying voltages

Working Voltage (KV)	spacing bet <sup>n</sup> Conductors
6.6 KV	76 mm
11 KV	101 mm
33 KV	190 mm

\* Generally pole brackets are used to hold the cross-arm with the poles.

\* Clamps are made up of flat iron and are used for fixing as well as holding service lines, stay wire, shackle insulators, cross arms etc.

### 3. Insulator :-

The main funct<sup>n</sup> of ~~a~~ insulator in distribut<sup>n</sup> line is to avoid the direct contact b/w charged conductor and earth.

\* The commonly used material for overhead insulator is ~~porcelain~~ glass or ceramic

We have following type of insulators are used for distribut<sup>n</sup> system

#### (a) Pin type insulator .

20-01-17

##### a) Pin Type Insulator :-

→ This type of insulator is used in 200 v, 400 v, 11 kv & 33 kv

##### b) Disc type Insulator :-

\* Disc insulator is categorised in two types depending upon its use.

i) If it is vertically arranged then it is known as suspension insulator.

ii) If it is horizontally arranged then it is called as strain insulator.

\* This insulators are used from 11 kv onwards,

for minimum no. of insulator disc required for transmission line are:-

Voltage in KV	suspension Assembly (No. of Disc)	Tension or Dead end assembly No. of Disc
11	01	01
33	02	03
66	05	06
132	09	10
220	14	15
400	21	22

### c) shackle type insulator.

This insulator is used only in L.T distribution up to 400 V.

\* This insulator are used in the street light purpose.

### d) Egg insulator.

It is commonly used in stay for H.T as well as L.T lines.

\* Its shape is like egg.

### 4. Conductor.

In distribution conductor plays a vital role to transmit the electrical energy & to circulate the electric current.

Hence the conductor is a medium of electric supply system.

Generally use A.A.C (All aluminium Conductor) & A.C.S.R

(Aluminium Conductor still Reinforced), as the overhead conductor in the distribution line.

In real practice conductors are placed various configuration like horizontal, vertical & triangular.

While stretching the conductor we must have to maintain a specific clearance among the conductors called as conductor spacing & also b/w the ground is called as ground clearance.

A general formula used to get conductor spacing of the allowable minimum conductor

$$\text{spacing} = \sqrt{s} \times \frac{\sqrt{V}}{100}$$

where,  $s$  = sag of the conductor  
 $V$  = line voltage.

The conductor clearance of the various voltage is written below

Supplied voltage (kv)	0.4	11	33	66	132	220	400
spacing (m)	0.2	1.2	3	2.5	3.5	6	4.5

Similarly the ground clearance in different locations given below

Supplied voltage (kv)	0.4	11	33	66	132	220	400
Across street (m)	5.8	5.8	6.1	6.1	6.1	7	8.4
Along street (m)	5.5	5.5	5.8	6.1	6.1	7	8.4
other areas (m)	4.6	4.6	5.2	5.5	6.1	7	8.4

### 5. span length:-

Depending on the supplied voltage of the distribution as well as transmission line we have following spans for the various types of supports.

a) for wooden supports span is (40-50) m

b) for rail poles span is (50-80) m

c) " RCC or P.C.C pole span is (80-200) m

d) for steel tower span is (200-400) m

For never crossing long span about 800 m may be considered which exceptional.


### 6. lightning arrester :-

It is a device which protects all the electrical equipments from damage due to surge voltage of lightning hence all the over head Conduitor are also connected with the lightning arrester at its substation, grid etc.

Q) Stay & crugs:-

co

21/01/17



Stay is basically used to provide supports to the lines pole whose are in balanced erection.

\* Generally stay is done at an angle up to less than  $30^\circ$  for L.T lines.

\* for H.L line the stay angle varies from  $45^\circ$  to  $60^\circ$ .

\* In the stay we use I.M.S rod of 19 mm dia, stay bow and cheese nut, we also use stay wire eighteen or  $\frac{3}{8}$  SWOT or  $\frac{7}{10}$  SWOT CT.I (Galvanised iron) one anchor plate of size 450 mm  $\times$  450 mm  $\times$  6.1 mm having 4.8 mm hole at the centre.

\* usually the depth of stay is approximately 1.67 m keeping a length of 46 cm of the rod projected above the ground level.

### 8) Phase plate.

To identify the colour codes of overhead conductors such as red (R), yellow (Y), Blue (B) such phase plates are attached with the supports.

### 9) Danger plate.

usually this plate is placed at a height of 2.4 m from the ground on the support.

\* This plate contains rating of voltage.

\* This plate is used to aware the human being

### 10) Barbed wire / Anti climbing.

This wire is provided around the poles at a height of 2.5 m from the ground from at least meter it is used no to climb any unauthorised / unauthorised.

### 11) Bird guard.

\* These are the wooden pieces of size about (10x12.5x15) in case metal poles and are fitted under the insulator.

\* Bird guard are used to avoid short circuit or earth fault due to the striking of birds which may short circuit any two live conductor or one live conductor to the ear.

### 12) Jumpers.

Jumpers are the conductors which are used to continuity supply line from one point to another point by jumpering.

\* Jumpers are generally used in D.P (Double Pole) structure and where disconnect<sup>n</sup> of supply line is existing

### 3) Marding wire

It is used to protect the life of human beings as well as wild life.

\* These are used in the place or locations of road crossing, over the telephone line, railway crossing, street crossing etc.

Q) Electric supply to a factory is to be taken from an 11 kV overhead 3-p line for a distance of 1 km from the existing 11 kV line. If this line meant for 300A load, prepare a list of materials required for this purpose. Assume a road crossing in this distribution line & take the span length is 80m.

23-01-2017

calculation of no. of poles or supports.

$$\text{Total line length} = 1 \text{ km} = 1000 \text{ m}$$

$$\text{Span length} = 80 \text{ m}$$

$$\text{No. of span} = \frac{1000}{80} = 12.5 \approx 13 \text{ (say)}$$

$$\text{Hence No. of poles required} = 13 + 1 = 14$$

Since road crossing is there so ~~so~~ one pole is required for this purpose

$$\therefore \text{Total no. of poles required} = 14 + 1 = 15$$



Calculation of no. of cross arms.

Let us select angle iron cross arm at thelapping pole as well as leaded pole & rest of the intermediate pole let us select V-shaped cross arm.

Hence no. of angle iron cross arm required = 2 no.

No. of V shaped cross arm required = 13 nos

Calculation—

for no. of insulators

According to the above line dig. strain insulators are used at the lapping pole as well as leaded pole and rest at the intermediate poles we use 11 KV pin type insulator.

Hence 11 KV strain (disc) insulator required  
 $2 \times 3 = 6$  no.

no. of 11 KV pin insulators required is equal to  
 $11 \times 3 = 42$  nos

Calculation for length of overhead conductor

Net span length = 3% total length + 2% for sag,

~~3(80+2)%~~ ~~200%~~

3060

Considering 120 meter/m for twisting and binding  
at the tapping zone as well as deadend zones, lumping

$$\text{Gross length} = 3060 + 62 = 3122 \text{ m}$$

### Selection of over head conductor

From the conductor chart for the current rating of 305A at  $40^{\circ}\text{C}$  ACSR,  $6/1 \times 4.50$ , cat type overhead conductor should be selected.

### Material table -

SL NO	description	specification	quantity
1	supports	RCC 9 m	15 no.
2	cross arms with its fitting accessories	(a) V cross arm (b) angle iron cross arm width 100 mm height 150 mm thickness 15 mm	12
3	Insulator with its fitting accessories	(a) disc type 11 KV (b) pin type 14 KV	6
4	over head conductor	ACSR $6/1 \times 4.50$ cat type	3072 m
5	Birding wire at the rate 100 mm per insulator	aluminium type (single core)	4.2 kg
6	stay with its fitting accessories	for H.T line	3 set
7	Earthing with its fitting accessories	H.T Line pipe earth	5 set
8	angle iron cross arm to support the grade wire	100 mm x 50 mm x 7.5 mm x 1.5	25
9	ground wire	CZ type 14 SWG	45 meter
10	anti clamping wire at 8 meter from pole	size 1.5 mm	$15 \times 3 = 45 \text{ meter}$

12. Surgeries to complete work

as per required

Ques: Prepare and estimate for H.T line for a 24-07-201 a distance of 8 km using ACSR Conductors to transmit for 800 kW load at 0.85 power factor in 3 phase 11 KV line draw the diagram of structure with cross arms and insulators. Assume or other necessary data.

Calculation the number of poles

Total line length = 8 km = 8000 m

Assume that span/length = 100

$\therefore$  Number of span  $\frac{8000}{100} = 80$  number

Hence number of pole required or support =  $80 + 1 = 81$  number



Calculation for no. of cross arms

Here 2 types of no. of cross arms are there.

$\Rightarrow$  V shape cross arms & angle iron cross arms  
calculation of insulator.

Here disc type insulator are required,  $273 = 6$  no.

Here pin type .. " " "  $3 \times 80 = 240$  number

Conductor calculation for length of over head conductor.

Let span length =  $3 \times 8000 + 24 = 24,480$

~~Consider~~ Consider for twisting & binding aluminium single core wire are required quantity 12 meter.

$\therefore$  total span length =  $24,480 + 12 = 24,502$

Selection of over head conductors

given that  $P = 800 \text{ kW}$   
 $\leftarrow 800 \times 10^3$

$$V = 11 \text{ KV}$$
  
 $\leftarrow 11 \times 10^3 \text{ V}$

we know that,  $\cos \phi = 0.85$

$$P = \frac{V^2}{Z} VI \cos \phi$$

$$I = \frac{P}{V \cos \phi}$$

$$\leftarrow \frac{800 \times 10^3}{11 \times 10^3 \times 0.85} = 49.39 \text{ A}$$

∴ line conductor  $49.39$

∴ short cut current  $49.39 \times 2 = 98.78 \text{ A}$

from the conductor table for current rating of

18.8 A at voice BSSR

6, 2, 11 over head conductor  
squirrel type should be selected  
material table.

Sl No.	Description	Specification	Quantity
1	Support	REC or PCC = 4	81
2	Cross arms with its fitting & cross arm accessories	V-cross arm angle iron made arms 100mmx50mmx1.5mmx1.5mm	39 number
3	Insulator with it's fitting accessories	Disc insulator 11 KV pin type insulator 11 KV	6 no. 240 no.
4	over head conductor	BSSR 6 x 1.50 cat type	24,492
5	binding wire at the rate 1 mtr of wire per insulator	Aluminum single core	21.4 kg
6	stay with it's fitting accessories for one line		3 set
7	W... with the ...	Conductor size 11m	2 m

8	guide wire angle wire crosstie arm	100 mm x 50mm x 1.5mm x 1.5 mm	2 m
9	sanger plate	for 11 kg	80 no.
10	anti climbing 3m open pole	192 type	12 m. lg.

CH-6

## Substation

24.1.17

In general practices subst<sup>n</sup> are different types depending on their nature of duty, service operating voltage and its design.

→ Depending on the design subst<sup>n</sup> can be divided in to 2 types

- ① Indoor subst<sup>n</sup>
- ✓ ② outdoor "

\* Again the outdoor type subst<sup>n</sup> are of 2 types

- ① pole mounting subst<sup>n</sup> (which is feasible 125 kV at same)
- ② Plinth " " (which is feasible 250 kV at same)

## Symbols of various types of apparatus used in subst<sup>n</sup>

25.1.17


SL NO	Description	Symbol
1	Earthing	
2	current T/F	
3	Potential T/F	
4	Fuse	
5	Isolation	
6	CBI breaker	
7	Bus bar	
8	Lightning arrester	

## Tandem isolator

Q) Draw a neat sketch of 125 kVA, 50 Hz, 1% - 44 KV substation and prepare list of material required for this purpose assume that taking the primary side SOSC conductor of squirrel type & the secondary cable takes as a pure aluminium conductor/cable

Ans

Neat sketch:-



Pole mounting  
substation

# Material Table

31/01/2016

SL NO.	descriptn	specification	quantity
(A)	for H-T Arrangement		
1	supports	Rail pole, 12 m	2 no.
2	cross arms with its fitting ass.	MS type, 100mmx50mmx2.5mmx 2 m	2 no.
3	strain insul. with its fitting accessories	Disc type, 11 KV	3 no.
4	lightning arrester with its fitting ass.	for 11 KV	3 no.
5	Earthing with fitting accessories	for 11 KV, pipe earthing	3 set
6	stay with fitting accessories	for H-T	2 set.
(B)	for A-B switch arrangement		
7	cross arms with its fitting access.	MS type, 100mmx50mmx2.5mmx2m	2 no.
8	Angle iron cross arm to fix the insul. with fitting accessories	MS type, 100mmx50mmx2.5mmx2.5m	3 no.
9	pin insulator with fitting acc.	for 11 KV	6 no.
10	crang operated (C.R.O) switch with 6 m long O.D PIPE along with its handle locking arrangement	for 11 KV	1 set
(C)	for drop out arrangement		
11	cross arm with fitting acc. ass.	MS type 100mmx50mmx2.5mm x 2 m	2 no
12	Angle iron cross arm to fix the pin insul. with fitting ass.	MS type 100mmx50mmx2.5mmx 0.75 m	3 no.


13	pin insulator with fitting accessories	for 11 KV	6 no.
14	splicing red or orange red to be instead in pin type insulator to support the explosion fuse wire	for 11 KV	6 no.
15	explosion type fuse wire to be instead in each phasor	for 11 KV at subst	1.5 m
D. for T/F Installation			
16	cross arms with fitting accessories ms type, 100mmx50mmx5mm x 20 m	2.80 PCD	
17	angle iron cross arm to be used as base plate of T/F	ms type 100mmx50mmx5mm D=75 m	2 no.
18	channel cross arm to support the ms type 100mmx50mmx5mm x 20 m	2 no	
19	T/F Transformer	125 KVA, 1/2 univ, 50 Hz, core type	1 no.
20	earthing with fitting accessories	for 11 KV, pipe earth	2 set
21	LT Cable	aluminium type, 4 core pvc insulated, 650 grade	5 m
22	LT Cable box	650 grade with removable type fuse units, outdoor type	1 set
23	Jumper conductor from H9 to T/F bushing @ 4m per phase	ACSR, 6/0x2.11 stranded type	12 m
24	Binding wire at the rate 10 gm per pin insulator	single core, aluminium type	102 kg
25	danger plate for t/f	for 11 KV	2 no.
26	antielectrolytic wire	crz type	6 m
27	surficies to complete the whole job	—	As per man

~~1~~ Prepare the list of material required for "slight mounting  
subst" of 10 kV, 50 Hz, 250 kVA T/F. The substation is  
50 m away from the existing n.v. line, uses D.P structure  
for the safety equipment arrangement and draw the neat sketch.

~~SOL~~ 02/02/2017

neat sketch

slight  
sub-station  
mounting



Calculation for length of over head conductor :-

$$\text{Net length} = 3 \times (\text{Declared} + 2\% \text{ for sag}) \\ = 3 \times (50+1) = 153 \text{ m}$$

Considering 6 m extra for twisting & binding at the tapping pole as well as deadend pole

$$\therefore \text{gross length} = 153 + 6 = 159 \text{ m}$$

### Material table

Sl No	Description	specification	Quantity
A	For H.T. arrangement		
1	supports	RCC, 9 m	2 no.
2	cross arms with fit. arrange for tapping pole	MS, 100mmx50mmx7.5mmx1m	1 no.
3	cross arms with fit-access for supporting strain insul.	MS type 100mmx50mmx7.5mmx2m	2 m
4	lightning arrestor	for 11 KV	3 no. set
5	strain insulator with fitting accessories	disc type, 11 KV	6 no.
6	Earthing with fitting acc.	for 11 KV, Pipe earth	3 set
7	Stay with its fitting access	for HT line.	3 set
8	over head conductor	ACSR, 6/1x4-50, cat type	159 m
B	AB switch arrangement		
9	Cross arms with fitting access	MS type 100mmx50mmx7.5mmx2m	2 no.
10	Angle iron cross arm to fix the pin insulators with fitting acc.	MS type, 100mmx50mmx7.5mmx2.5m	3 no.
11	Pin insulators with fitting acc.	for 11 KV	6 no.
12	AB switch with 8 m long(?) pipe along with its fitting acc with handing fitting arrang.	for 11 KV	1 set
C	for drop out arrangement		
13	Cross arms with fitting acc.	MS type, 100mmx50mmx7.5mmx2m	2 no.
14	Angle iron cross arm to fix the pin insulator with fitting acc.	MS type, 100mmx50mmx7.5mmx2.5m	3 no.
15	pin insulator with fitting	for 11 KV	6 no.

16	Splicing ring mounting rod to be installed in pintype insul to support the explosion fuse wire	for 11 KV	6 no
17	Explosion type fuse wire for T/F installation	for 11 KV/100 V	1.5 m
18	Base plate for T/F installation	102 mm x 50 mm x 7.5 mm x 0.5 m	2 no
19	C-c. plinth for T/F installation		—
20	Transformer	250 kVA/ 11 KV/100, 50 Hz Core type for 11 KV, pipe earthing	1 no.
21	Earthing with its fixing access	2 set.	
22	Jumper conductor at the rate 4m per phase from lightning arresters to T/F installation	PCSP, FR-450 coil type	1.2 kg
23	Binding wire at the rate 10gram per pair insulation	aluminum type, single core	2.2 kg
24	Anti climbing wire	CR-I type	
25	Danger plate, 11V	11x11	6 m
26	LT cable	4 Core, aluminium type with PVC insulator, 650 grade	2 no.
27	LT Cable box	650 grade with renewable type fuse unit, cut down by PC	1 set
28	surficies to Complete the whole job	—	As per my

### short questions

07/02/2017

- 1) where & why CR-O switch is used  
Ans - Gang operated switch is used in different substn as well as D.P structure of H.T lines
- 2) It is used to make & break the existing line
- 3) what is TP MO switch & where it is used  
Ans - TP MO switch means triple pole manually operated switch.
- 4) It is used in 3P line like distribution substn to make & break the supply lines

Q Write the various types of outdoor substn?

A outdoor substn are of two types

- ① pole mounting substn
- ② plinth ..

Q what is the max<sup>n</sup> rating of T/R which is installed in pole mounting substn

A generally up to 250 kVA rating T/R was used in pole mounting substn

Q state any four types of substn according to their ser.

A According to service Categories substn will be categorized into following groups

- 1) T/R substn
- 2) switching substn
- 3) converting ..
- 4) frequency changing substn

Long Q.

V.V. Imp

1. A 37 kW substn is to be given to an agriculture fie. and 415 V, 3-ph, 50Hz, the connect<sup>n</sup> is to given from a 3.8 km overhead line this is available at a distance of 40 m. The full load efficiency is 85%. & P.F=0.8. make a neat sketch showing how will you arrange the supply by a pole mounting substn & estimate the quantity of material required it

2. Prepare the list of material with neat sketch for install<sup>n</sup> of a plinth mounted 750VA, 110/220V distribut<sup>n</sup>. The 11 KV line is available 30m away from the proposed site

# overhead Installation :—

(LT distribution)

Q) A 1 km long overhead distribution line, 440 volt 50 Hz is to be erected along the street road from the 100 kVA,  $\frac{1}{2}$  MVA pole mounting sub-shalt. The line is to be laid with  $\frac{1}{2} \times 300$  mm ACSR conductor on the pole of 9 m long. write a list of material required. Assume the span length to be 30 m also draw a rough sketch of this line.


Soln Calculation the no. of poles

Over head length 1 km = 1000 m

Suppose span length = 30 m

No. of span = 20

No. of pole req:  $20+1 = 21$  no.



single line dig.

Calculation of no. of cross arm angle iron type.

for pole 21<sup>st</sup> cross arms are 21 & tapping the line from ~~from~~ the subshalt we have to be used one more cross arm

Hence

Total no. of cross arm required =  $21+1 = 22$  no.

\* for insulator calculation,

There are 3 insulators used for 3<sup>rd</sup> other one insulator is used for neutral conductor

Each intermediate pole has four no. of Pin type insulator hence total no. of pin issued are  
 $10 \times 11 = 110$  no.

at the substation end and at the dead pole shackle insulator are to be used.

Hence total no. of shackle are required =  $2 \times 4 = 8$

\* Calculation of length of overhead conductor

Total length of conductor =  $w \times (\text{decreased length} + 2 \times 5\%)$

Consider 10 m extra for twisting & binding, gross length =  $\frac{w \times 1000 + 10}{0.95} = 4080 \text{ m}$

Practically not used now a days

\* Select<sup>n</sup> of overhead conductor & cables

As per the given data, for overhead conductor AS IS, 6/1x3.00

& for LT cable we choose 3-P 4 core, 650 grade PVC insulated cable.

\* material list

Sl.no	Description	Specification	Quantity
1	Pole	RCC, 9 m	21 no.
2	Cross arms with fitting accessories, MS, 180mmx25mmx15mmx 1.5 m		22 no.
3	Insulator with fitting accessories	a) Pin insulator, 400V b) Shackle insulator	80 no.
4	overhead conductor	$\frac{6}{1} \times 3.00 \text{ mm}, \text{ASISR}$	0.90 m
5	Binding wire at the rate of 100 g per insulator	Aluminium type (single core)	4000 m 8 kg.
6	Stay with fitting accessories	for L.T. line	2 set
7	Earthing with fitting accessories	Pipe earthing, 100 mm dia	5 set
8	Anti-climbing wire at the rate of 3 m per pole	CTI type	63 m
9	Danger plate	For 440 V/0.44 KV	21 no.
10	L.T. cable	3-P 4 core 650 grade PVC insulated	10 m
11	Sundries to complete the whole Job		As per required

Prepare an estimate for a distribution line with street lighting is to be distributed from a 100 mVA, 400 V over a distance of 1 km. Calculate the size of ACSR conductor to be used also prepare the list of material required for it and sketch the path of distribution line

10/02/2017

### Calculation for no. of supports

To find length 1 km = 1000 m.

assume span length = 50 m

$$\therefore \text{no. of spans} = \frac{1000}{50} = 20$$

∴ Supports  $20 + 1 = 21$  

### Calculation for cross arm

Here all angle iron cross iron require

for 21 pole 21 no. Cross are required

for tapping 1 cross arm required  $21 + 1 = 22$

### Calculation for insulator

Here two type insulator are required

① Pin type insulator - 100 no.

② shackle insulator - 10 no.

\* Here street light Conductor is required so we

\* ~~the~~ 3 phase & 50 wire system is occurred.

\* we use intermediate pole, pin insulator

### over head conductor length calculation

$$5 + (1000 + 20) = 5100 \text{ m}$$

for binding the wire 10 m required extra

$$5100 + 20 = 5120 \text{ m}$$

No of street light is now ~~\* LED street light~~

~~for RT poles~~ A street light is required 21 LED's  
selected for overhead conductor :-


$$\text{Given} = P = 100 \text{ WVA} = 100 \times 10^3 \text{ VA}, V = 440 \text{ V}, \cos \phi = 0.8$$

$$\therefore P = V^2 / Z_{\text{eq}} \Rightarrow Z_{\text{eq}} = \frac{V^2}{P} = \frac{100 \times 10^3}{\sqrt{3} \times 440} = 131.2 \Omega$$

$$\text{short circuit current} \Rightarrow I_{sc} = V / Z_{\text{eq}} = 440 / 131.2 = 3.34 \text{ A}$$

for 3.34 A we selected conductor from the conductor table  
Aluminum ACSR 4/8 x 4.00 which maxm current carrying capacity is 270 A.

Sl No	Description	Specification	Quantity
1	Pole	9m R.C	21
2	Cross arm with fitting accessories	insulator 100 mm - 750 mm	21
3	overhead conductor	ACSR 4/8 x 4.00 mm	5120 m
4	Insulator with fitting accessories	E.I type insulator	100 no.
5	Binding wire per insulator (each)	stainless type aluminum (single core)	10 kg.
6	Stay with fitting accessories	for LT line	2 sets
7	Earth with fitting accessories	PIPE earth for L.T	1 set
8	Artificializing wire per 400E	U.V type	6.3 m
9	Danger plate	for 1100 V	21
10	Bird guard	10 mm x 12.5 mm x 15 mm	110 no.
11	street light with fitting acc.	LED, 90, 230V	21 nos.
12	flexible wire at the rate of 3m per street light	CA, 230V, copper wire	6.3 m
13	L.T cable	30 Jumbo 5	10 m
14	Surchiech to complete the whole job.	- - -	No per require d



Q) An over head distribution line of 440V, 3-phase 50 Hz is 13-02-17  
 to be erected along a straight road. The length of the line is 300m  
 and the end supports are terminal structures. The span between  
 adjacent poles is 50 m. make a neat sketch of the terminal p  
 showing disposition of the conductors.

The conductors on the overhead line are as follows

- i) phase wire - hard drawn copper conductor of number 4/2
- ii) neutral & street wire - Hard drawn bare copper conductor of number 1
- iii) earth wire - core (galvanised steel) core of no. 8/50m.

Prepare the list of materials required for this process.

Calculation for no. of supports

Total length of the distribution line = 300m

Span length = 50m.

$$\text{No. of poles} = \frac{300}{50} = 6 \text{ No.}$$

No. of total span = 6+1 = 7



Calculation no. of cross arms :-

since the no. of poles is 7 so 8 cross arms required

Calculation for insulators:

According to the rule we use shackle insulator at the tapping pole feidend poles as well as intermediate pole.

3 insulators are used for 3 phases other but insulator were used for neutral & street light.

40 insulators are used for earth conductor  
 hence,

Total no. of shackle insulator are required.

$$8 \times 5 = 40 \text{ no.}$$

Total no. of pole insulator required  $8 + 1 = 9 \text{ no.}$

# Calculation of length overhead Conductor.

i) Calculation for length of phase wire (u.s.w.c.n):-

$$3 \times (300 + 6) = 918 \text{ m}$$

Take 5m for binding = 923 m

ii) Calculation for neutral & street wires (S.S.W.C.N)

$$2 \times (300 + 6) = 612 \text{ m}$$

Take 5m for twisting & binding = 612 + 5 = 617.


iii). Calculation for Earthing wire (C.I.S. type S SWG):-

$$1 \times (300 + 6) = 306 \text{ m}$$

Take 5m for binding = 306 + 5 = 311 m.

in Table:-

No.	Description	specification	Quantity
1	supports	arc, 9 m	7 no.
2	cross arms with fixing accessories	60 mm x 24 mm x 2.5 mm x 1.5 m ms	7 no.
3	Insulator with fixing accessories	shuttle, type	45 no.
4	" "	fixing type	8 m
5	over head conductor for phasing	Copper conductor 4 SWG	928 m
6	over head conductor for neutral & street light wire	Copper conductor 2 SWG	612 m
7	over head conductor for earth wire C.I.S. type, 8 SWG	Copper type Single core	311 m
8	Binding wire at the rate 100g	COPPER type Single core	3 kg
9	stay with its fittings	for L.T. wire	2 set
10	Earthling with fixing accessories	for L.T. line pipe	3 set
11	Anti-climbing wire 3m per poly	earthing type	21 m
12	Danger Plate	for 400 V	4 no.
13	street light with its fitting accessories	1.5 m x 90 x 230 v	7 set
14	flexible wire at the rate 3m per street light	1A, 230v, Copper conductor	71 m
15	Switches for street light	6A, 230V, 1-6	7 no.
16	L.T. cable	3.0 mm², 3 core PVC insulated	10 m
17	Sentrich to complete the	-	85 per req.



### short question

- (1) (a) which type of insulator is used in hot line.  
→ Pin & sleeve
- (3)(b) what is the permissible angle for the stay installation of LT line.  
→  $230^\circ$  to  $45^\circ$
- (3)(c) what is the specification of stay wire which is used in stay installation  
 $\frac{7}{10}$  SWG CRZ wire
- (4) what is the ground clearance of LT distribution line running the street across the street?  
→ The ground clearance of the LT distribution along the street is 5.5 m & across the street is 5.8 m.
- (5) where stay stay installation is required?  
→ The stay installation is required at the tapping pole, dead end and deviation poles to maintain the unbalanced mechanical force of a particular supports of over head line.
- (6) what is the length to be buried in the ground of a pole in the normal soil?  
→  $\frac{1}{6}$ .
- (7) why the core of service cable service cable is must be selected as aluminium  
→ The Core of service cable is selected as aluminium because the over head Conductor at the service pole is also aluminium. Hence to avoid interrupt of energy supply.

## CH-5 over head service connection

14-01-12

### 1-φ service connect<sup>n</sup>

The over head line or cable or under ground cable connecting b/w the supplier line & Consumers premises is called as service line or service connect<sup>n</sup>.

The service Connect<sup>n</sup> may be two types depending on the phase that are.

- i) 1-φ service connection
- ii) 3-φ service connection

Depending on the field situation it may be of two types.

i) over head service connect<sup>n</sup>

ii) under ground service connection

Important points to be remember:-

\* If the service pole is situated more than 45 m from the consumer premises then over head line may be used like pole brackets.

\* If consumer premises more than 50 m from the service pole then one ~~or~~ intermediate pole may be used.

\* If the consumer load doesn't exceeds to 1000 then 10 sets hard drawn copper conductor may be used.


\* If the consumer load doesn't exceeds to 25 kW then 8 sets copper conductor or  $13.9 \text{ mm}^2$  A.A.C conductor may be used.

\* If the consumer load doesn't exceeds to 12 kW then 6 sets soft copper or  $19.4 \text{ mm}^2$  A.A.C conductor are used.

a) prepare the list of material required for providing a service connection to a 1-ph stirred building at 240V 1- $\phi$ , 50 Hz having light & fan load of 5kw. The supply is to be given from an overhead line 20m away from the building & also draw the rough sketch.

50V

16/02/2015



Given -  $V = 240 \text{ V}$ ,

$$P = 5 \text{ kW} = 5 \times 10^3 = 5000 \text{ W}$$

$$f = 50 \text{ Hz}$$

Calculat<sup>n</sup> of short out current:-

Given -

$$P = 5 \text{ kW} = 5000 \text{ W}, F = 50 \text{ Hz}$$

$$V = 240 \text{ V}$$

$$\cos \phi = 0.8$$

We know that,

$$P = V I \cos \phi$$

$$I_L = \frac{P}{V \cos \phi} = \frac{5000}{240 \times 0.8} = 26.04 \text{ A}$$

∴ Short out current

$$I_{SO} = 1.5 \times I_{SL} = 1.5 \times 26.04 = \boxed{39.06 \text{ A}}$$

Select<sup>n</sup> of service cable

Though out  $I_{SO}$  is 39.06 A but from the Conductor table it is observe that for the current rating of 43 A a pvc insulated twin core aluminium conductor of  $\frac{7}{1.70}$  mm dia,  $16.0 \text{ mm}^2$ , 240 V is to be selected.

Calculat<sup>n</sup> for length of service cable.

Net length = declared length + 3 m of sag + 1 mt coil at the pole + 0.5 mt coil at the gi pipe + 1.5 mt from the coil to overhead conductor + 1 mt curvature + 3 mt along the pipe + 0.3 mt for wall thickness + 0.3 mt for meter clearance = 28.2 m

Considering 10% extra for fitting & cutting

$$\therefore \text{Cross length} = 28.2 + 2.8 = 31 \text{ m}$$

$$= 28.2 + 2.82 = 31.02 \text{ m}$$

Calculated for length of CTI wire

1+10X11

Net length = declared length + sag 3m + 1m at the pole

+ 0.5m at the CTI pipe =  $20 + 0.6 + 1 + 0.5 = 22.1$  m

Calculation for length of aluminium clip.

Let us assume length of each aluminium clip is equal to 10 cm

spacing of the clip is

spacing of the clip is 20 cm

$$\therefore \text{No. of aluminium clips required} = \frac{20\text{m}}{20\text{ cm}} = \frac{2000 \times 10^2}{200} = 100 \text{ no}$$

$$\therefore \text{length of the aluminium clip } 100 \times 10 = 1000 \text{ cm} \\ = 10 \text{ m}$$


### Material Table

SL NO	Description	Specification	Quantity
1	over head cable	7.50 mm dia, twin core aluminium type, 16.0 mm <sup>2</sup> 2no roll	31.02 m
2	support wire	10 SWG, CTI type	22.1 m
3	Aluminium clip to hold the cable with the support wire	Aluminium type, 38 mm dia	10 m
4	service pipe	CTI type, 3m height, 1-Ø	1 no.
5	clamps to support the CTI pipe from the wall with fitting accessories	CTI type with appropriate diameter	3 nos
6	crutties	wooden type	6 no.
7	Energy meter	240V, 50 Hz, 1-Ø, digital type	1 no
8	Board to fit the energy meter with fitting accessories	45x60 cm with 13A cover	1 set
9	kit var fuse	1-Ø, 240 V, 32A	1 set
10	sundries to complete the whole job		RS per need.

DR

Q) Prepare & estimate the quantity of material required for providing a service connect to double store building with a load of 5.5 kW at 240 V, 50 Hz, separate meters are to be provided for two floors and the distance bet<sup>n</sup> the pole & building is 15 m

18/02/2017



### Calculation of short cut current.

$$P = VI \cos\phi$$

where  $P = 5.5 \text{ kW} = 5.5 \times 10^3 \text{ W}$   
 $V = 240 \text{ V}$

Assume  $f = 50 \text{ Hz}$   
 $\cos\phi = 0.8$

$$I = \frac{5.5 \times 10^3}{240 \times 0.8} = 28.64 \text{ A}$$

∴ short cut current  $1.5 \times 28.64 = 42.96 \text{ A}$

### Selection of service cable.

From conductor chart we selected, PVC insulated twin core 7/1.70 mm<sup>2</sup> 43A, 16.0 mm<sup>2</sup> range cable, for 42.96 ampere

### Calculation for length of cable.

Net length = distance length + 3 m for sage + 1 m coil at the pole + 1 m coil at the gi pipe + 1.5 m from coil to the over head conductor + 1 m for Conduiture + 3 m along of the gi pipe + 0.3 m for will thickness + 0.3 m for meter clearance + 2 m for second meter thickness

= 24.55 m. Considering 10% extra for twisting & binding

Cross length of conductor =  $24.55 + 2.455 = 27.005$  m

Calculation for one support wire  
Declarer length 43% of sag + 1m at pole + 0.5 m +

twisting = 16.95 m

clipping at the pole

Calculation for length of aluminum clip

20th Feb 17

Spacing betw the clamp = 20cm

i. No of clip required =  $\frac{1500 \times 1}{20 \text{ cm}} = 75 \text{ no.}$

ii. Length of C.R. clip =  $75 \times 10 = 75 \text{ cm} = 7.5 \text{ m}$

### Material list

SL NO	DESCRIPTION	SPECIFICATION	QUANTITY
1	over head cable	thin core, $\frac{1}{10} \text{ mm}^2$ , 43A $16.0 \text{ m}^2$ , 240V	27 m
2	support wire	inner in pipe	16.95 m
3	Aluminium clip to hold the cable	38 mm dia.	1.5 m
4	service pipe	CR type 30 m I-Ø	2 no.
5	clamp to support the pipe appropriate diameter with fixing accessories CR type.		3 set
6	crutching	wooden type	6 no.
7	Energy meter	50 Hz, 240V, 1-Ø, digital type	2 no.
8	Board with fixing accessories to fix the meter	45x60 cm with its board	2 set
9	vit met fuse	I-Ø, 240V, 32 A	2 set
10	sundries to complete whole job	.....	as per require.

## Short questions :-

- 1) Which type of cable is used for service connection?  
Ans generally for service connect we used P.V.C. insulated weather proof aluminium cable
- 2) Differentiate various types of service connect?  
Ans generally service connect are of two types, depending on the field situation that are
  - 1- overhead service connect
  - 2- underground
- 3) What is the size of aluminium clips used to hold the cable with the support wire in case of service connect?  
Ans The minimum size of aluminium clips used to hold the cable with U.I. wire is 38 mm
- 4) Why the U.I. pipe is bend back in the upper end with opening facing downward for carrying the cable in service connect?  
Ans The U.I. pipe is used for carrying the cable in service connect has been made bend back to prevent the entry rain water in to the pipe.

## long questions

- 1) Prepare and estimate the materials required for installing of overhead service connect to residential building having a load of 1.3 kW standing a distance of 24 m along a road of 1.3 km from the nearest pole of supplier. Also draw a neat sketch.
- 2) Estimate the quantity of materials required for providing a service connect to a double stayer building with a load of 14 kW at 240 V, 50 Hz, separate meters are to be provided for two floors. The distance bet<sup>n</sup> the pole and building is 12 m and the distance bet<sup>n</sup> service bracket & service board 10 m.


CH-5

22 Feb

3-Phase service Connection

Problem A farmer required to connect a 37 kW, 440 V, 500 motors from a 3-phase wire overhead line. The distance of service line from the farmer's structure having the motor is 15 m. The motor has an efficiency is 85%. & PF of 0.8. Estimate the quantity of materials required for this purpose and also draw the neat sketch.

Neat sketch.



Calculation of short circuit current.  $\rightarrow$   
Given that

$$\text{out put, } P_o = 37 \text{ kW}$$

$$V = 440 \text{ V}$$

$$F = 50 \text{ Hz}$$

$$\cos \phi = 0.8$$

$$\eta = 85\% \approx 0.85$$

we know that

$$\eta = \frac{P_o}{P_i} \Rightarrow P_i = \frac{P_o}{\eta} = \frac{37}{0.85} = 43.52 \text{ kW}$$

$$43.52 + 10^3 \text{ W}$$

Again:-

$$P_i = \sqrt{3} V_i I_i \cos \phi$$

$$\Rightarrow I_i = \frac{P_i}{\sqrt{3} V_i \cos \phi} = \frac{43.52 + 10^3}{\sqrt{3} \times 440 \times 0.8} = 71.38 \text{ A, per phase}$$

23<sup>rd</sup> Feb-17

short circuit current  $I_{SC} = 27 \text{ A}$

selected for service cable =  $27 \times 1.38 = 36.76 \text{ A}$ .

From the conductor table it observe that for the current rating of 36.76 A a aluminium conductor paper insulated lead cover ~~110 volt~~, 5mm<sup>2</sup>, u-core common under Jong table should be selected in which the max current carrying capacity is 158 A.

Calculation for length of pvc pipe.

Net length = declared length + length from L.T box of underground + vertical meter clearance  
 $= 15 [4.5 + 0.2 + (2 + 0.2)] = 21.9 \text{ m} \approx 22 \text{ m}$

calculation for length of under ground cable:-

Net length = vertical distance for overhead conductors under ground + declared length + meter clearance  
 $= 4.5 + 1.5 + 0.5 + 1.5 + 2.2 + 0.2 = 23.9 \approx 24 \text{ m}$

Consider 10% extra for twisting & cutting

$$24 + 2.4 = 26.4 \text{ m}$$

calculation for no. of CT clamp:-


Assuming the distance betw 2 clamps to be 1 m.  
As per dig. we need 6 no. of clamp with its fitting accessories.

## material table

SL NO	DESCRIPTION	SPECIFICATION	QUANTITY
1	under ground cable	aluminium conductor paper insulated, $50 \text{ mm}^2$ 4 core armored cable	26.4 m
2	LT cable box with its fitting are	LT outdoor type	1 no.
3	Clamp to hold the cable with pipe	CCT type, appropriate diam.	6 no.
4	PVC pipe for underground system	PVC, appropriate diameter	22 m
5	Energy meter	3Ø, 400 V, 50 Hz, digital	1 no.
6	Board to fix energy meter with fitting accessories	45 x 60 cm with its cable	1 no.
7	TCRN switch with fuse unit (iron plate) triple pole with auxiliary line	200 A, 400 V, 50 Hz	1 set
8	sundries to complete the job		As per stan.

(Q) A Farmer house wants 3Ø, 4 wire power connect to his house which is situated at a distance of 50 m. from the nearest service pole. make a neat sketch showing the arrangement of supply & estimate the quantity of material required. Assuming the efficiency of motor is 85 %

1st march - 17



(readers note short out cur)

$$P = 7460 \text{ W} \quad 1 \text{ HP} = 746 \text{ W}$$

$$V = 400 \text{ V}$$

$$\eta = 85\% \quad 0.85$$

$$F = 50 \text{ Hz}$$

$$\cos \phi = 0.8$$

$$\eta = \frac{P_o}{P_i} = \underline{P_i} = \frac{7460}{0.85} = 8776 \text{ W}$$

$$P_i = \sqrt{3} I_L V, \cos \phi$$

$$I_L = \frac{8776}{\sqrt{3} \times 400 \times 0.8} = 14.3 \text{ A}$$

$$\text{Short out cur, } I_s = 2.4 \times 14.3 \text{ A} = 28.78 \text{ A}$$

Selection for service conductor.

From conductor table, we select for the carrying of 28.78 A, aluminium conductor, paper insulated lead covered, 1000 V, 6 mm<sup>2</sup>, 4 core armoured underground cable should be selected in which the max current rating is 48 A.

Calculation for Length of pvc pipe.

$$\begin{aligned} \text{Net length} &= \text{declared length} + \text{length of pit box of underground} \\ &\quad + \text{vertical clearance} = 50 + 4.5 + 0.2 + 0.2 + 2 \\ &= 56.9 \approx 57 \text{ m} \end{aligned}$$

Calculation for under ground service wire

Let Length = declared length + vertical length of ~~over ground~~ of the over head conductors to the under ground of + 0.5

$$\text{Water Clearance} = 15.5 + 4.5 + 0.2 + 2 + 0.2 = 58.9 \approx 59 \text{ m}$$

for twisting we need 10 m extra

Circumference      Cross length = 6m.9 ≈ 6.5 m

## Catalaf™ for CTI clamp

Assume the distance betn 2 clamp to be 1m As per dig  
we need 6 no. of clamp.


### Table :

Sl No	Description	Specification	Quantity
1	under ground cable	aluminium conductor paper insulated 1100V, 6mm <sup>2</sup> u core armoured type	65 m
2	LT cable bar with ftrg access	CTI outdoor type	1 no.
3	Clamp to hold the cable with tube	CTI type appropriate diam	6 nos
4	PVC pipe for underground system	pvc type- appropriate diameter	57 m
5	Energy meter	3-ph, 400 V, 50 Hz digital type	1 no.
6	Board to fit the meter with ftrgs.	45 x 60 @ 60 cm its longer	1 no.
7	ICTPN switch with fuse drift	400 V, 50 Hz	1 set
8	sunbridge to Compl the job.	.....	As per required

# Electrical Installation (Household wiring)

## Wiring system:-

It is defined as a network of wires connecting with various electrical loads from supplier meter boards through the safety & controlling devices.



Various system adopted for distributing electrical energy.


In our Country basically following two types of system's are adopted for distributing energy.

1. Distribution board system -

2. Tree system .

1. Distribution board system.


3<sup>rd</sup> march 19



This is one of widely used energy distribution system in our country.  
\* This system has an iron clad on each cut, one cut out must have to be installed on the iron clad or board, so this board is sometimes called as fuse board or distribution board.

- \* For every cut phase & neutral wires must be taken from the respective bus bars which is also fitted on the distribution board.
- \* In this system each cut must contain ~~10~~ to pull on 800 amperes.

## 2. Tree system -



\* This system is not used frequently due to the following reasons -

- 1. The extra load can't get the feeding voltage due to resistance drop.
- 2. The fuses are scattered which causes more expensive.
- 3. For each cut phase & neutral wires are taken from the connectors and neutral links as shown in above figure.


## Methods of wiring -

Generally we have two types of methods

for wiring that are


1. Joint box system
2. Loopin system

## 1. Joint box system



- \* It is also known as Tee system
- \* In this system phase & neutral wires are connected with the joint box as shown in above figure
- \* Each electrical load phase wire is to be taken from the joint box through the switch & neutral wires from the joint box directly to the load by this way for each number of electrical loads are connected
- \* Joint boxes are used accordingly switches are used
- \* This method is a costlier method because large number of joint box is used  
hence this method is not adopted now a days.

## 2. Loop in system



In this system phase wire is to be controlled by the switch and the same phase is to be connected to a particular load as shown in above figure.

\* The neutral wire is directly connected to the each load by not through the switch

These system of wiring is mostly used now a days

Wiring materials and accessories:-

#### as conductor

Generally conductor is a medium through which electric current can easily flow.

Following are the important materials that are used for the conductor

#### 1. Copper

# Copper material is used as a best material for conductor

+ Its conductivity comparatively very high

\* At  $20^{\circ}\text{C}$  of temp the resistivity of copper is  $1.796 \times 10^{-8} \text{ ohm}$

\* The specific weight of copper is  $8900 \text{ kg/m}^3$

\* It has high resistance to corrosion, oxydation & spitting

#### 2. Aluminium

\* In the electrical field basically in transmission distribution utilization it dominates the copper material

\* It is the next immediate choice of material for the conductor

\* Its resistivity is  $2.8 \times 10^{-8} \text{ ohm}$

\* This material is less cost and used in different cables as well as overhead bare conductors

\* It is also affected by oxydation

### 3. Silver (Ag)

\* Even though this material has high conductivity as compare to copper but due to its very cost it is not used frequently.

#### b) Wires & Cables:-

The term wire is very much familiar in wiring system which meaning is a strip of hair conductor with negligible thickness.

\* Similarly the term cable is also a popular word used in wiring system. Its meaning is a wire covered with the insulating material.

\* A cable may be single core, double core, or more core.

#### c) Types of insulating material:-

following are the important insulating material that are used in various electrical fields

1. Rubber

2. V.I.R (Vorganized Indian rubber)

3. Impregnated paper

4. P.V.C (Polyvinyl chloride)

5. Silk & Cotton

#### d) properties of Insulating material:-

The purpose of insulating materials used in cable or covered with the hair conductor is to prevent leaking current from the conductor or core.

Following's are the important properties of insulating material -

1. High resistivity

- 2. High dielectric strength
- 3. High flexibility
- 4. Not flammable
- 5. High resistance to moisture, acids & alkalies.
- \* Cables of withstand high temp
- \* Cables of withstand high withstanding voltage

8th mar - 17

### c) Mechanical protection

Generally a cable should be design in such a manner that it can help mechanical stability.

- \* Usually in power cables to protect against mechanical injury who two layers of still paper are used or now a days aluminum sheathing is introduced

### f) Types of cable used in Internal wiring

11th mar - 17

\* Generally cables are categories based on conductor used

- 1- number of cores
- 2- Amount of voltage supply
- 3- Types of insulation

Ques

Hence following's are the important cables used in internal wiring

1) VIR Insulating Cable (240v/400v & 650v/1100v)

2) TRS or CIS cables (240v, 400v & 650v, 1100v)

(Tough rubber sheath) (cable, tyre sheath)

3) Lead sheathed cable (240v/400v)

4) PVC cable (240v / 400v & 650v / 1100v)

3) weather proof cable (200V/400V & 650V/1100V)

4) XLPE cable - such cable's are build of the insulation's are made up of Polymers. Polymers are the substances which consisting of long macro molecule. Such cable's are used in high voltage supply purpose.

5) General specification of cables

while purchasing or estimating the Cable must emphasize

1 size of cable

2 types of conductor used (aluminium or copper)

3 number of core (1-core, double core, three core etc)

4 voltage grade (200V/400V or 650V/1100V etc)

6) Main switch & distribution board

According to IE rule so a suitable Circuit switch has to be provided immediately after to the meter board.

following are the important specification of main switch according to there application

1) 200V, 16A, DPIC switch for two wire DC ext or 1-p AC

2) 200V DPIC (double pole iron clad) 440V, 650V, 32A or 62 A or 100A DPIC switch for 3-w DC ext

3) 440V, 32A or 64A or 100A DPIC switch with neutral link for 3-w AC ext

Similarly for distribution boards we have main specification has 2 ways, 3 ways, n ways etc.

### i) Conduit

Generally in house hold wiring we use following type of Conduits

- 1) light gauge steel Conduit
- 2) Heavy gauge steel Conduit
- 3) flexible Conduit
- 4) pvc Conduit

### j) Conduit accessories and fittings :-

In the wiring system basically for 15<sup>th</sup> march - 17 Conduit wiring following accessories are frequently used.

- 1. Bend Conduit
- 2. Bushing or Coupler
- 3. Clips & Saddles
- 4. Conduit boxes (2-way, 3-way etc)

### k) Lighting accessories & fittings :-

\* For lighting purpose we used following accessories

fittings.

### l) switches

Various types of switches are used in house hold wiring that are

- 1. 1-way switch, 2-way switch, 3-way centre of switch

4. Double pole main switch

5. push button switch

6. Table lamp switch

7. Dumbell or surface switch

ii. Ceiling rose switch

Ceiling rose may be of 2 plates or three plates.

\* Three plate ceiling rose is basically used in  
Ceiling fan

iii. Socket outlet

Depending on the field application a socket may be  
2-Pin, 3-Pin, 5-Pin or 6Pin of 250 V, 6A, 16A, 32A & AC.

iv. Lamp holder

We have following types of Lamp holder

1. Batten holder

2. Pendant holder

3. angle holder

4. slanting holder

5. Bracket holder

6. Water tight bracket holder

7. miniature lamp holder

For the above holder the specification may be

SA, 250V Bayonet holder of any lamp

## Q. 1. What is a fuse?

Fuse is defined as a small safety device which is used for interrupting an electrical circuit under excessive flow of current or short circuit current.

(i) Element of material used for the fuse -  
Generally tin, lead, silver, copper, zinc, aluminium & alloy of lead & tin are used as the materials for fuses. But commonly an alloy of lead & tin with a proportion of combine of 3P:1.8G:1.1 is used for in fuse for the small current rating purpose (up to 16 A).

\* Beyond 16 A or excessive of current normally we uses copper as the fuse material even though the cost of silver is very high still then for heavy current (more than 100 A) this material is used for fuse.

### (ii) Types of fuse:

Depending on the use of fuses it classified into following types

① supply main fuse → This fuse is provided by the supplier & agencies.

\* It is fixed just after the service meter board.

② Consumer main fuse → This fused is placed just after the consumers main switch.

\* The current of this fuse is comparatively < that of the supply main fuse.

~~(ii) Sub cut fuse~~

As we know the total wiring system is divided in to no. of short cut so for each sub cut we connect or fix a fuse which is called as subcut fuse.

(iv) Point fuses →

For good quality of wiring the individual load point such as - lamp, fan, washing etc containing fuses called as point fuses.

(v)

Fusing factor

It is defined as minimum fusing current to the current rating of fuse element.

$$F.f = \frac{\text{minimum fusing current}}{\text{current rating of fuse element}}$$

(vi)

Breaking capacity.

It is defined as the rating of a fuse corresponding to RMS value of the respective current and the system voltage.

(vii) Fuse unit.

A fuse ~~unit~~ consist of metal fuse element or ~~the~~ link set of the fuse.

\* Depending on the field applied

Fuse units are of following types.

1. round type fuse unit
2. Kitkat or rewirable fuse unit
3. Cartridge type fuse unit
4. High rupturing capacity fuse unit (HRC)

## M. Protective devices

used in domestic as well as

industrial wiring

Generally for overloading or any type of abnormal condition or any type of short circuit we use some protective devices such as -

1. fuses
2. relays
3. MCB
4. Earth Link cut breaker (ELCB)

## N. Earthing system

We know that earthing is defined as a connection of the neutral point of the supply system & not current carrying parts of electrical apparatus such as - metallic frame work, metallic covering of cables, earth terminal of the socket outlet & stay wires etc to the general mesh of the earth so as to immediately discharge the electrical energy into the earth without any danger.

## Resistance of earth

According to IE rule the earth resistance should be low enough to cause the flow of electric current quickly.

- \* The earth resistance is not equal in all places because it depends on the moisture contains of soil & types of the soil etc.
- \* There are following important value of the earth resistance that can be permitted

1. In large power station ( $0.5\Omega$ )

2. major power stat<sup>n</sup> ( $1\Omega$ )

3. small subst<sup>n</sup> ( $2\Omega$ )

4. In all other cases ( $5\Omega$ )

\* The resistance from the earth plate to any point in the installat<sup>n</sup> should be one ~~same~~.

The size of earth continuity consider normally.

1<sup>st</sup> Swg or 16 swg or 18swg CTI or Copper wire

2<sup>nd</sup> In general the distance of earc electrode from the building should not be less than  $1.5m$

## Methods of earthing

following method's are adopted for earthing

## 1. strip or wire earthing -

for copper wire diameter is 25 mm x 1.6 mm &

for CTI wire diameter is 25 mm x 0.8 mm

## 2. rod or spike earthing -

Various rod are available in market for earthing that are -

i. 12.5 mm solid rod copper of 2.5 m long

ii. 16 mm solid rod of CTI of 0.75 about 2.5 m long

We also used 25 mm CTI of 2.5 m long

3. Pipe earthing - The pipes are available in different size are 40 mm width 2.5m long CTI. And 19 mm CTI & 1.5 m long.


## 4. plate earthing.

Different size of plate's are available for plate earthing are -

for Copper - 160 cm x 60 cm x 3 mm

for CTI - 60 cm x 60 cm x 6 mm

unwind layer.




MATERIALS LIST

Job Earth

SL No.	Description	Specification	Quantity
1.	Earthing plate	Copper type, 60cmx60cm x 3.8 cm	1 no.
2	pipe	CTI type 10 mm &	2.5 m
3	Pipe for earth wire with it's fitting accessories.	CTI type 12.7 d	3 m
4	wire	CTI type 16 SWG	1.5 kg.
5	Tugs	for 6 SWG wire	2 no
6	Nut & bolts	10 mm, CTI bolt	5 no.
7	CTI frame box	30 cm x 30 cm	1 no.
8	Cast iron cover	30x30 cm	1 no.
9	Funnel with wire mesh with it's fitting accessories	-	2 set.
10	charcoal	-	10 kg
11	Salt	-	10 kg
12	Sundries to complete the whole job.	-	AS per measur. ,

# Pipe Earthing



material table

price  
each

SL NO.	description	specification	quantity
1	cni pipe in under ground	38 mm dia	2.5m
2	cni pipe for watering	19 mm dia	1.5 m
3	cni regulating Bucket with it's Fitting accessories	(38x19) mm	1 set
4	cni pipe for incoming of earthing wire	13 mm dia	4 m
5	cni wire for earthing	6.5mm	12 m
6	cni bolt & nut with fng. acces.	(10x33) mm	2 no
7	cni bend for incoming cni Pipe	13 mm dia	1 no
8	Cast. iron frame	30 cm <sup>2</sup>	1 no
9	cast iron cover	30 cm <sup>2</sup>	1 no
10	funnel with wire mesh	—	1 no
11	charcoal	—	10 kg
12	Salt	—	10 kg
13	Cement Concrete	1:4:8	0.15 m <sup>3</sup>
14	sundries to complete the whole job	—	As per required.



## System of wiring:

16<sup>th</sup> mar-19

In the wiring system (may be domestic or industrial) following important wirings are adopted

- (a). cleat wiring
- b. wooden Casting & Capping wiring
- c. CTS or TTS or lead sheath wiring
- d. Conduit wiring

### Cleat wiring



\* At first in this wiring system demarcation is on the wall surface using hand drill's holes are made along the demarcation at 30 cm to 60 cm apart. Then wooden gullets (plugs) of size 38 mm x 38 mm of 6.5 cm long are placed in the drilling holes.

The base cleat having two groups, three groups etc are to be fixed on the g�ties. Then VIR cables are taken through the groups of the base cleat & immidenly after it the top cleat is screwed over the base cleat. Now the cables are gripped or placed in the cleats.

#### Advantages

- \* It is the easiest method or way of installation.
- \* Fault finding is very easy and repairing also requires very less time.
- \* Dismantaling is easy & quick in this method.
- \* No skilled person will required.

#### Disadvantages

This is a temporary wiring system.

- \* It is not good looking
- \* Since the cable is exposed to <sup>air</sup> wire so it may be chemically affected which causes damage to the insulation
- \* The wires or cable are exposed to mechanical injury

#### Applicability

This wiring system is basically used in unclamped places and also where a temporary wiring system is needed.

## CTs or TRS lead seath wiring

In this wiring system "demargat" is given on the wall surface using hand drill, holes are made along the "demargat" at 75 cm apart. Then wooden gutties or plugs of size 38mmx8mm of 6.5cm long are placed in the drilled holes. Then for holding the cable clips are made with an pinned brash are fixed on the batten with an interval of 10 cm in case of horizontal & 15 cm in case of vertical. Then thin wood batten of different size as applicable such as (13x13)mm, (19x13)mm, (25x13)mm, (31x13)mm etc. are fixed over the gutties by means of screws or wooden plugs with appropriate size. Then CTs or TRS cables are laid over the nail pins and after it the nail pins are twisted, so as to hold the cables permanently.

For providing the number of cables & pin's the different size of battens are mention below :

Batten size	No. & size of Link clip	No. of single core cable to be carried out ( $1/1.44 \text{ mm}^2 \text{ cu}$ )
13 mmx 13 mm	1x 38 mm	0.2
19 mmx 13 mm	1x 50 mm	0.3
25 mmx 13 mm	2x 38 mm	0.4
31 mmx 13 mm	1x 38 mm & 1x 50 mm	0.5

## Advantages

- \* it is highly durable
- \* it can withstand the action of acids & alkalies
- \* It is good looking as compare to wooden casings & keeping wiring.
- \* Its installation is easy
- \* Fault finding & maintenance is easy.

## Disadvantages

- This system is very costly now a days
- \* Skilled labour is required for making the smooth pattern
- \* There is a risk of fire


## Application

This type's of wiring is used for installation in domestic, Commercial or industrial except workshop

## J. Conduit wiring

In this wiring demarcation is given on the wall surface using hand drill p/c's, the holes are made along the demarcation at 75 cm apart. Then wooden gutties of size 32mm x 8mm of 6.5 cm long are placed in the drilled hole. Then the based saddle is ~~is~~ fixed on the gutties in proper manner the PVC pipe is immediately piped over this base and immediately the saddles are fixed on the screwed its eight ends.

This is the procedure for surface wiring.



- \* In Case of Conduit wiring the wall surface is to be burried along the demarcation then pvc or cct pipe are placed inside the plaster by means of saddle Crampet's.
- \* It may be surface or Conduit Conduit for drawing the cables through the pipe, 18 gauge of wire is used.
- \* This wiring system is frequently used now a days
- \* The size of Conduit or pipe that available in market are 12mm, 16mm, 20mm, 25mm, 31mm, 38mm & 50mm but large size according to our <sup>out side diameter</sup> is 63mm is also used

### Advantages

- \* It is free from electric shock
- \* The whole system is water proof
- \* It is highly durable
- \* It give protection against fire
- \* It is protected from mechanical damage

## Disadvantages

- \* Its installation is not easy
- \* fault finding is very difficult
- \* Repairing is also very difficult.

## b) Wooden Casing & capping wiring

In this wiring demarcation is given at the wall surface at a height of 3m from the ground using the hand drill holes are created along this demarcation line with in 15 cm apart. The wooden gutties or plug of size ~~size~~  $32\text{ mm} \times 8\text{ mm}$  about 6.5 cm long are inserted in the drilling hole. Then wooden casing (may be 2 groups, 3 groups etc) is fixed on the gutties by means of screws the length of such wood gutties about 2.5m to 3m. After it PVC or VLR cable are drawn through the groups of the casing then to cover named as capping is now screened over the casing

## Advantages

- \* To some extend it is easy to install
- \* Even though cables are damaged but no short cut takes place in the casing because phase & neutral wire are placed separate groups
- \* In this system fault finding is easy
- \* Repairing is also easier than constilt wiring.

## Disadvantages

- \* It is very high cost now a days
- \* It is not used in damp place
- \* It has risk from fire/hazard.

## Application

This wiring system basically used in low voltage (250v) domestic wiring normally in dry place where not have firing risk.

## short Q.

1) Define fusing factor

Ans It is defined as the minimum fusing current to the current rating of the fuse element.

$$\text{math. f.f.} = \frac{\text{minimum fusing current}}{\text{current rating of fuse element}}$$

2) write the various types of insulating material which are used in cable.

Ans Various type of insulating material are

1) PVC insulating material

2) VIR "

3) Impregnated paper insulating material

4) Rubber insulating material

5) cotton & ~~synthetic~~ silk

3) write the various properties of a insulating material which is used in used in cable.

Ans Various properties are

1) High dielectric strength

2) High resistivity

3) high malleable, high resistance to moisture

w) which type of material used in fuse for small current rating purpose.

Metallic lead & tin fuse element used in small current rating purpose

- 5) write the types of system of wiring.  
System of wiring are various types such as—
  - 1) cleat wiring
  - 2) wooden Casing & capping wiring.
  - 3) CTC or TRS or lead sheath wiring
  - 4) Conduit wiring.

long a:

1) write the various types of system of wiring and describe any two methods of system of wiring and also write advantages & disadvantages

### Switches

CNO - Change operated S.

TPMO - Triple pole manual operated S.

TPIC - " " iron plate S.

DPIC - Double " " S.

Push pull switch

Dumb or surface switch

Double pole main switch

1-way switch

2-way switch

2-way centre of switch

~~Disadvantages~~

~~F~~ This is a risk of hazard.

- \* It is not used in damp places
- \* It is very costly in nowadays

~~Application~~

This wiring system is basically used in low voltage (250 V) domestic wiring, normally in dry places where there is no fire risk

~~Q1-3~~


### Electrical installation

18<sup>th</sup> mar 17

Problem:-

Two 3 $\phi$  415 V, 50 Hz squirrel cage motors are to be installed in a workshop, the rated data of the motors and their locat<sup>n</sup> are shown in given below. A  $\Delta$  starter supplied with each motor is to be installed on the wall. The supply company meter will be located at the pos<sup>n</sup> mark. The wiring of the m/c's is to be carried out according to the IIE rule. Make ~~or~~ neat sketch of this wiring with the help of single line dig. indicating the no. & size of cables used. Also prepare a list of material required for the wiring including necessary earthing with CTI plates of 60mmx60mm x 6 mm.

~~Neat sketch~~



### Symbols used

SL NO	Description	symbol
1	Energy meter	(circle)
2	main switch	(rectangle)
3	switch board with switches	(rectangle with internal lines)
4	distribution board	(rectangle)
5	socket outlet	(D)
6	phase wire	(solid line)
7	neutral line	(dashed line)
8	Earth wire	(solid line)
9	fuse	(infinity symbol)
10	starter	(envelope symbol)


### Assumption -

For Industrial wiring installation following assumpt<sup>n</sup> must be consider

- \* Height of H.R (horizontal run up) from the ground is 3m
- \* Height of the main switch (MS) and distribut<sup>n</sup> board is 2m to 2.5m
- \* Height of the motor switch starter & switch board is 1.5m from the ground
- \* Height of the plinth for placing electrical m/c is 0.2m or as visible
- \* The depth of the trench is 0.2m
- \* The wall clearance shouldn't be less than 1m
- \* There shouldn't be wood work in the wiring installat<sup>n</sup>.
- \* Looping on the cable must be avoided
- \* Jointing of the cable must not be allowed
- \* The cable shouldn't be turned with 90° or more.
- \* Two separated earthing must be provided to each electrical m/c

### wiring plan

20<sup>th</sup> mar-17



4. Calculated for short out current :-

26<sup>th</sup> Mar 17

Let us assume input voltage or supplied voltage,

$$V_L = 415 \text{ V}$$

$$f = 50 \text{ Hz}$$

$$\eta = 85\% \Rightarrow 0.85$$

$$\cos\phi = 0.8 \text{ lagging}$$

For 15 HP motor :-

$$\text{O/P power, } P_o = 15 \text{ HP} = 15 \times 746 = 11190 \text{ W}$$

$$\text{we know that } \eta = \frac{P_o}{P_i} \Rightarrow P_i = \frac{11190}{0.85} = 13164.7 \text{ W}$$

$$P_i = \frac{P_o}{\eta} = \frac{11190}{0.85} = 13164.7 \text{ W}$$

short out current ( $I_{SC}$ )

$$\text{Here } P = V_L I_L \cos\phi V_3$$

$$I_L \Rightarrow \frac{P}{V_L \cos\phi V_3} = \frac{13164.7}{415 \times 0.87 \sqrt{3}} = 22.89 \text{ A}$$

$$I_{SC} = 22.89 \times 2 = 45.78 \text{ A}$$

for 10 HP motor :-

$$P_o = \text{O/P power} = 10 \text{ HP} = 10 \times 746 = 7460 \text{ W}$$

$$\text{we know that } \eta = \frac{P_o}{P_i} \Rightarrow P_i = \frac{P_o}{\eta} = \frac{7460}{0.85} = 8776.47 \text{ W}$$

short out current ( $I_{SC}$ )

$$\text{Here } P = V_3 V_L I_L \cos\phi$$

$$I_L = \frac{P}{V_3 V_L \cos\phi} = \frac{8776.47}{\sqrt{3} \times 415 \times 0.8} = 15.26$$

$$\text{Hence } I_{SC} = 15.26 \times 2 = 30.52$$

Total short out current both the motor,  $I_{SC} = I_{SC1} + I_{SC2}$

$$I_{SC} = 45.78 + 30.52 = 76.30 \text{ A}$$

### 5 Selection of cable :-

- 1) Since total  $I_{sc}$  for both the motor is  $76.35 \text{ A}$  so from the Conductor table it is observe that for 3 core Copper conductor through rubber sheath cable of  $19/1.80 \text{ mm}, 3.0 \text{ mm}^2, 650 \text{ V grade}$ , for  $88 \text{ A}$  cable should be selected
- 2) since the  $I_{sc}$  current for 15 hp motor is  $45.8 \text{ A}$  so from the Conductor table we select for the max<sup>m</sup> current rating of  $52 \text{ A}$ ,  $19/1.80 \text{ mm}, 25.0 \text{ mm}^2, 650 \text{ V grade}$  Cable and is to be selected with though rubber sheathed
- 3) since the  $I_{sc}$  for 10 Hp motor is  $30.57 \text{ A}$  we uses 30 A wire because sum  $30.57 \text{ A}$   $\frac{4}{4.0} \text{ mm}, 1.0 \text{ mm}^2, 650 \text{ V grade}$  cable is to be selected with though rubber sheathed

### 6. Selection of main switch:-

Since the  $I_{sc}$  of entair load is  $76.3 \text{ A}$  so we should select T.P.I.C (Triple pole iron clad),  $45 \text{ V}, 100 \text{ A}$  with persoliv material is to be selected

### 7. Selection of distribut<sup>m</sup> board :-

Since in this case there are two electrical m/c so two way 415 volt grade iron clad with Cooring system and different grade of fuse or cut off or to be fixed as per the  $I_{sc}$  of 15 HP & 10 HP motor

8. Coal draft" for Length of cables for 15 HP motor (25.00